



Exploded View



Components - Panels

Please check that you have all the components listed below before constructing your item.








Part No	Description	Qty	Size (mm)	Thickness (mm)
1	BOTTOM RAIL	2	650x75	15
2	BOTTOM SIDE RAIL	2	310x75	15
3	BOTTOM PANEL	1	650x340	15
4	BOTTOM FRONT PANEL	1	620x330	15
5	BOTTOM BACK PANEL	1	620x330	15
6	LEFT BOTTOM SIDE PANEL	1	330x295	15
7	RIGHT BOTTOM SIDE PANEL	1	330x295	15
8	FRONT BOTTOM TOP PANEL	1	620x175	15
9	BACK BOTTOM TOP PANEL	1	620x150	15
10	TOP BACK PANEL	2	1098x393	3
11	CENTRAL STRIP	1	1090x100	15
12	RAIL	1	590x80	15
13	UPPER PANEL	1	598x188	3
14	TOP PANEL	1	640x160	15
15	LEFT TOP SIDE PANEL	1	1350x150	15
16	RIGHT TOP SIDE PANEL	1	1350x150	15

Important – Please read these instructions fully before starting assembly


Components - Fixings

Please check that you have all the components listed below before constructing your item.


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)	CAM lock dowel x36 	**(B)**	CAM lock x36 	**(C)**	Wood dowel x22 	**(D)**	Screw x13 
(E)	Wall anchor x2 	**(F)**	Screw x20 	**(G)**	x12 	**(H)**	Wood Screw x2 
(I)	x2 	**(J)**	x2 	**(K)**	x4 	**(L)**	Screw x12 

Tools Required




Ruler – Use this to measure your screws (mm)




Important – Please read these instructions fully before starting assembly


Assembly Instructions

01




02






03

B x4




04

D x8




05

B x4




06


B x10



07


D x5	F x12	J x2
		







08

A x2	B x4
	








09




10








11



B x4



12



F x8




K x4




13

G x12	L x12
	



14

I x2



15

E x2	H x2
	

